XGFEC2525

Radio frequency identification XG, field expander universal type, Sn 26...150 mm, 250 x 250 x 10 mm



Main

Range of product	Telemecanique Radio frequency identification XG		
Accessory / separate part type	Field expander		
Product specific application	Universal		
Product compatibility	XGCS4901201 + XGHB440245 XGCS4901201 + XGHB90E340 XGCS4901201 + XGHB320246 XGCS4901201 + XGHB221346 XGCS4901201 + XGHB320345 XGCS4901201 + XGHB520246		
Accessory / separate part destination	Station with associated label		
[Sn] nominal sensing distance	26150 mm		

Complementary

Accessory dimension	250 x 250 x 10 mm
---------------------	-------------------

Packing Units

Unit Type of Package 1	PCE
Number of Units in Package 1	1
Package 1 Height	9.000 cm
Package 1 Width	29.700 cm
Package 1 Length	30.000 cm
Package 1 Weight	542.000 g
Unit Type of Package 2	S04
Number of Units in Package 2	6
Package 2 Height	30 cm
Package 2 Width	40 cm
Package 2 Length	60 cm
Package 2 Weight	4.039 kg

Offer Sustainability


Sustainable offer status	Green Premium product	
California proposition 65	WARNING: This product can expose you to chemicals including: Diisononyl phthalate (DINP), which is known to the State of California to cause cancer, and Di-isodecyl phthalate (DIDP), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov	
For all Reach Rohs enquiries contact us at	sustainability@tesensors.com	

Contractual warranty

Warranty 18 months	
--------------------	--

Dimensions

Field Expanders




(1) 4 x M4 screws

XGFEC2525

Minimum Mounting Distances


Distance Between Field Expanders



Tag	e1	e2	e3
XGHB90E340 XGHB520246	570	890	960
XGHB320345	720	1275	1200

Minimum Mounting Distances in a Metal Structure

Distance Between Field Expanders




Field expanders	
e (mm)	h (mm)
0	75

XGFEC2525

Curves


Dialogue Zones for Field Expanders



(1) Recommended working zone.

Curves

Dialogue Zones for Field Expanders



Recommended working zone.